

Floor Estimator Pro / Commercial Shortcut List

Onscreen Plan Takeoff

Wheel
Wheel Down
Plus/Minus (+,-) Keys

Functions

Zoom in and out
Pan and shift rooms and plan
Zoom in and out

Room Selection

Ctrl+A
Ctrl+Left Mouse Button
Left-Mouse Rubber-band

Select all rooms in the current layer
Pick to select multiple rooms
Drag out rectangular area to contain rooms to highlight

Free draw Mode

Ctrl+Z
Space, or Right-click,
or Double Click
Esc or Right-click

P key
R key

Undo one step (before free draw finishes, or reopen a closed room)

Close free draw shape
Quit free draw mode
Stop drawing, allow to re-start drawing by clicking on either end points
Turn current drawing segment into curve

Insert Doorway

Space key
X key
Shift key

Flip side
Toggle different door leaf style
Switch door leaf axis

Delete Rooms or Fixtures

Delete key

Delete any highlighted items (rooms or fixtures)

Shift Selected Rooms

Arrow keys

Shift highlighted items up, down, left, right

Cut, Copy, Paste Rooms

Ctrl-X
Ctrl-C
Ctrl-V

Cut selected rooms
Copy selected rooms
Paste copied rooms

Show Wall Base Section, Walls

S key

W key

To show or hide wall base sections of all rooms
To show or hide walls and ceilings of selected rooms in 2D

GTCO Digitizer 16-Button Configuration

Button 0	Pick corner point while in free draw mode (beep once)	
Button 1	Undo pick corner while in free draw	
Button 2	Trace arc/curve wall	Toggle
Button 3	Redo corner pick	On/Off
Button 4	Restart free draw (abandon current points)	
Button 5	Close free draw shape	
Button 6	Enter into rectangular shape takeoff	Toggle
Button 7	Enter into attachment takeoff (takeaway areas, holes, insets, etc)	On/Off
Button 8	Enter into doorway takeoff (pick two door width points, second point with door leaf)	Toggle
Button 9	Enter into stairway takeoff (start from first step, pick four points: first two points define stairway width, third point AND 2nd point defines a single tread length, fourth point AND 1st point defines the total tread length.	On/Off